

Renny® JR.

The Loud Cell Phone Ringer™

MANUAL

Welcome!

Thank you for supporting a Dallas, Texas small business and purchasing Renny®JR, the most advanced *Bluetooth*® Ringer and Flasher on the market. Renny®JR connects automatically to your smartphone with our proprietary Autolinx™ technology, eliminating the need to manually connect when receiving calls or streaming audio. Renny®JR has an incredible range to accommodate most homes when placed in a central location such as a kitchen or living room. No other product this size offers the phone management technology offered by Renny®JR. We are confident that Renny®JR will become one of your favorite phone accessories!

QUICK START GUIDE

ATTACH ANTENNA

Screw included antenna into antenna connector.

TURN ON

Plug Renny®JR into an outlet with the supplied cord. Renny JR® automatically turns on. (To turn off Renny JR®, unplug it.)

INITIAL PAIRING

Go to your phone's Bluetooth settings to add a device (refer to your phone's manual.) Tap "Renny JR." on your phone to connect.

Renny®JR can only be connected to 1 phone at a time.

If you do not see "Renny JR." in phone's Bluetooth® settings, refer to your phone's manual & try resetting Renny®JR:

1. Insert a paperclip in the "RESET" hole on the bottom of Renny®JR.
2. Press firmly on the button multiple times until you hear

Renny®JR say "reset".

3. Unplug Renny®JR for 10 seconds.
4. Plug Renny®JR back in and try to re-pair on your phone.

SELECT OPERATING MODE

Slide the switch left or right to change between RING or MUSIC modes:

1. RING Mode: Renny®JR rings loudly when you receive an incoming call. All other sounds stay on your phone.

2. MUSIC Mode: All audio from your phone will play on Renny®JR, including all text/email notifications, music, media audio, etc.

SELECT RINGTONE

Short Press the MUSIC NOTE BUTTON to select the desired ringtone.

SELECT VOLUME

Press V- or V+ to select volume. A double beep will be heard when minimum or maximum volume is reached.

PHONE NUMBER ANNOUNCE

Press and Hold the MUSIC NOTE BUTTON until you hear the voice prompt to turn on/off phone number announce. (When on, Renny®JR will announce caller's phone number.)

IMPORTANT NOTES

No Battery - Renny®JR does not have an internal battery. Must be plugged into a wall outlet at all times.

No Microphone - Renny®JR is not a speakerphone and does not have an internal microphone to protect your privacy.

Not Recommended For Music - Renny®JR is designed to be a loud ringer and is not recommended for high quality music streaming.

SPECIFICATIONS

Working Voltage: 5V / Output Power: 3W

Size: W90*L90*H40mm / Weight: 203 Grams

Speaker Spec.: 52mm 4Ω 3W

Frequency Response: 80HZ-20KHZ

Distortion: ≤0.5% SNR: ≥95dB

WARRANTY

5 years, covers factory defects only. Damage from misuse,

impact or incorrect USB Adapter is not covered. No other warranties are covered or implied. See www.olenstechnology.com for additional warranty information.

SAFETY INFORMATION

WARNING! Please read these safety warnings and cautions to ensure your personal safety and prevent property damage.

Fire and Electric Shock Hazard

Do not expose Renny®JR to liquid, moisture, humidity, or rain. Do not use Renny®JR near a bathtub, sink, sauna, pool, or steam room. Exposure of Renny®JR to moisture could result in electric shock.

Do not drop, disassemble, open, crush, bend, deform, puncture, shred, microwave, incinerate, paint, or insert foreign objects in to Renny®JR. Such actions could result in electric shock.

Clean Renny®JR only with a dry cloth.

Do not expose Renny®JR to extremely high or low temperatures.

Do not leave Renny®JR in direct sunlight for extended periods of time.

Do not leave Renny®JR near open flames such as cooking burners, candles, or fireplaces.

Do not block any ventilation openings.

Adapter Hazard

Do not dispose of Renny®JR in a fire. It could explode causing injury or death.

Do not attempt to disassemble the Renny®JR because this may result in electric shock.

Do not use Renny®JR in damp areas or in extremely high or low temperatures because this could result in electric shock.

Do not clean Renny®JR when it is plugged in. Always unplug the adapter first before cleaning Renny®JR.

Automobile Accident Hazard

Do not leave or store Renny®JR or any of its accessories near or over your automobile's air bag because serious injury may result when air bag deploys.

Fall Hazard

Do not place Renny®JR on high surfaces such as shelves. During music playback Renny®JR may move which could cause Renny®JR to shift and fall off the edge.

CAUTION!

Do not use abrasive cleaners to clean Renny®JR because this could cause scratches and damage.

Do not bring Renny®JR in to contact with any sharp objects because this could cause scratches and damage. Do not insert anything into Renny®JR unless otherwise specified in the user instructions. This may damage the internal components.

Do not attempt to repair, modify, or disassemble Renny®JR yourself, it does not contain any user-serviceable components.

Use only the manufacturer supplied adapter to charge Renny®JR. Other adapters may look similar, but using them could result in electric shock and could damage Renny®JR.

Observe all signs and displays that require an electrical device or RF radio product to be switched off in designated areas.

Do not use Renny®JR inside an aircraft unless allowed by the airline.

Dispose of Renny®JR in accordance with local regulations.

FCC Disclaimer

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

This device complies with Part 15 of the FCC rules.

Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

Renny JR. is a trademark of Olens Technology. Android is a trademark of Google Inc. iPhone is a trademark of Apple Inc., registered in the U.S. and other countries. Bluetooth is a registered trademark of Bluetooth SIG. All other trademarks identified herein are the property of their respective owners.

© 2024 Ölens Technology. All Rights Reserved.