


# iLuv® SmartShaker®3



User Manual (Ver 1.2)

Bluetooth® 5.2

## APP OPERATIONS




- 100% Battery Status
- Bluetooth Status
- Setting Menu
- Toggle the On/Off of Individual Alarm
- Delete Alarms

## WHAT YOU NEED

- ▶ Any device with iOS10 / Android 5.0 or above
- ▶ A power charger or power bank

## WHAT'S INCLUDED




## DEVICE SETUP

### 1. Charge the SmartShaker 3

Connect the charging cable to the SmartShaker 3 and a USB-C power charger.

The 4 LEDs on the SmartShaker 3 will continuously blink white indicating that the device is charging.

The 4 LEDs will stop blinking once charging is complete.



## DEVICE SPECIFICATION

- **Dimension and weight**  
Dimensions: 3.9" X 3.9" X 1.3" (100mm X 100mm X 34mm)  
Weight: 170g
- **Compatibility**  
iOS devices with iOS 10 or above  
Android devices with Android 5.0 or above
- **Connectivity**  
Bluetooth 5.2  
Frequency, power and coverage:  
Bluetooth® frequency: 2404 – 2480 MHz  
Max output power: 2.5mW (4 dBm)  
Bluetooth® coverage: Up to 15 m ( 45FT )  
\* Coverage can be reduced by thick walls and large objects
- **Power and battery**  
Battery power: 1 x 1500mAh Li-ion Polymer Battery  
Power consumption:  
Active with strong vibration < 900mA Idle position < 200 µA  
Operating time: Up to 14 days per charge  
Charging time: about 2 hour 10 minutes @ 5V 1000mA, 25°C / 77°F
- **Cables and connections**  
Cable length: 1 m ( 3.3' )  
Contacts: USB-A to USB-C
- **Environmental requirements**  
For indoor use only  
Temperature: 15° - 35°C, 59° - 95°F  
Relative humidity: 5% – 95% (non-condensing)
- **What's include**  
SmartShaker 3 Main unit  
Charging cable  
Manual

## 2. Install the SmartShaker 3 App




Search and download "SmartShaker 3" on the Apple App Store or Google Play Store.

\*\* Please do not install SmartShaker+ App

## 3. Turn on Bluetooth on your mobile device.

## 4. Launch the SmartShaker 3 App and follow the instructions.

## DEVICE INTRODUCTION



### Snooze Button

- Press once to check battery
- Press once to snooze alarm if alarm is active

## FAQS

1. In the app stores which app is for SmartShaker 3?  
SmartShaker 3, not SmartShaker+
2. How long will the SmartShaker 3 continue to vibrate if left untouched?  
5 minutes.
3. How can I snooze the alarm?  
Press the snooze button on the device or press the snooze button on the App.
4. Can I customize the timing for the snooze interval?  
The default is 9 minutes however you can edit the timing by going to Menu -> Time Setting -> Snooze Interval.
5. How can I stop the alarm?  
Slide the Alarm button to off or press the off button on the App.
6. How can I enable alerts for incoming calls?  
Go to Menu -> Alert Setting and then toggle the "Alert for phone calls".
7. How can I enable alerts for incoming messages?  
Go to Menu -> Alert Setting and then toggle the "Alert for SNS Messages".

## TROUBLESHOOTING

1. My SmartShaker 3 isn't responding.  
Plug the SmartShaker 3 to a power source to make sure the device is fully charged. You can check the battery level by pressing the snooze button.
2. My app isn't connecting to my SmartShaker 3.
  - i. Make sure Bluetooth is enabled on your phone.
  - ii. Place the SmartShaker 3 and the connected phone closely together.

## On/Off Switch

- Off : Disable alerts for all incoming calls, messages and alarms
  - On : Enable alerts for all incoming calls, messages and alarms
- Please make sure the SmartShaker 3 is on.

## Reset Hole

- Factory reset for SmartShaker 3

## USB-C Charging Port

- Connected to any charging adapter / power bank / PC with 5V 1A output

## LED

● Solid Color Light ○ Blinking Color Light ● Light Off

	<b>All Blinking Blue</b> Pairing mode		<b>All Blinking Green</b> Incoming Call/Message*
	<b>All Blinking White</b> Active alarm*		<b>All Solid Blue</b> Firmware Update Mode
* LED settings must be enabled on the app.			
Battery LED indication after pressing snooze		LED status when in charging	
	75 - 100%		75 - 100%
	50 - 75%		50 - 75%
	25 - 50%		25 - 50%
	10 - 25%		< 25%
	< 10%		
* All LED will be off after charging finished.			

If this cannot help, try below.

- i. Force close the SmartShaker 3 App.
- ii. Toggle Bluetooth on your mobile.
- iii. Hard reset your SmartShaker 3.
- iv. Open your app again.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Hereby, iLuv Creative Technology declares that the radio equipment type SmartShaker 3 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the follow internet address : [www.iluv.com](http://www.iluv.com)

**TROUBLE SHOOTING:** When the battery is completely drained while not in use for a long period of time, try charging it a few times as it will resume its normal charging process. Restart the charging process if the charging indicator does not respond or is turned off after a few minutes.  
**DÉPANNAGE :** Lorsque la pile est complètement épuisée parce qu'elle n'a pas été utilisée depuis longtemps, tentez de la charger quelques fois afin qu'elle se remette à charger normalement. Recommencez le processus de chargement si l'indicateur de charge ne répond pas ou s'il s'éteint après quelques minutes.